

HIBY RS2

INSTRUCTIONS



使用说明书

前言

感谢您购买了HiBy推出的便携高清无损播放器RS2，为了让RS2给您带来更好的体验，这份说明书将介绍RS2的功能和使用方法，希望您更了解RS2，使用得更畅快。

HiBy RS2是一款采用基于Linux开发的HiByOS系统，搭载Darwin音频架构的高清无损数字音乐播放器，支持DSD、DXD、WAV、FLAC、MQA、MQA Studio、MQAcore(MQB)、ALAC、APE、WMA无损/有损、AIFF、AAC、MP3、MP2、Ogg Vorbis等多种无损/有损音乐格式。

按键与接口



- 1.触摸控制:屏幕为IPS多点触摸屏，2.45'、分辨率480*360;
- 2.电源键:关机状态向右拉两秒，即可开机;开机状态下拉住可关机;
- 3.RGB LED:会根据机器不同状态和当前歌曲采样率而变更颜色，颜色对应:

红色: 充电/低电量	白色: DSD
黄色: 32K~48K	绿色: MQA
青色: 64K~192K	蓝色: MQA studio
橙色: 352.8K及以上	紫色: MQA core (MQB)

4.TF卡: RS2以外置TF卡储存曲目，TF卡最大支持≤2T.首次放入TF卡卡需要进行歌曲扫描。TF卡安装在RS2内，而RS2以提供的USB线连上电脑时，在电脑上可看见该卡并将歌曲拖拉进去以拷贝歌曲，拔掉USB线前请在电脑中将卡“安全退出”。

5.Type C接口:数据传输+充电+同轴输出，同轴输出需要用专用的Type C转3.5mm同轴线，可到说明书最后列出的HiBy官方专营店购买。

6.耳机口:支持3.5mm单端耳机/3.5mm线路输出输出复用，支持4.4mm 平衡输出模式;通过机器设置切换线路输出模式。

7.电脑USB dac in: 请前往www.hiby.com官网下载相应驱动并仔细阅读相关说明；RS2作为USB DAC，需要在系统设置---USB模式---选择音频，并用数据线 with 电脑相连。

8.Uncharge模式：电源键向左锁定，USB dac in模式不充电

9.更多操作说明请扫描以下二维码并在“HiBy海贝音乐”公众号回复“RS2 说明书”



注意事项

- 不可擅自维修、拆卸和将产品放在有水的地方。
- 当长期没有使用本产品时，需要定期给产品充电，以保证电池寿命。
- 搭配电压过高的充电器充电可能会损坏机器，请选择推荐使用的充电器进行充电。
- 系统发生故障导致死机时，可尝试长按电源键30秒，强制重启机器。

电池使用注意事项

- 如果电池更换不当会有爆炸危险。
- 只能用同样类型或等效类型的电池来更换。
- 电池（电池包或组合电池）不得暴露在诸如日照，火烤或类似过热环境中。
- 消费者若使用电源适配器供电，则应购买配套使用获得CCC认证并满足标准要求的电源适配器。



English

Thank you for purchasing the portable HD lossless player HiBy RS2. To help you get the best out of the RS2, this user guide has been compiled to introduce you to the RS2's features and how to use them. Please read thoroughly in the first days of ownership.

The HiBy RS2 is a Linux HD lossless player with Darwin architecture, supporting various lossless / lossy DSD, DXD, WAV, FLAC, MQA, ALAC, APE, WMA lossless / lossy, AIFF, AAC, mp3, mp2, Ogg Vorbis etc.

MQA (Master Quality Authenticated) The HiBy RS2 includes MQA technology, which enables you to play back MQA audio files and streams, delivering the sound of the original master recording.MQA' or 'MQA Studio' indicates that the product is decoding and playing an MQA stream or file, and denotes provenance to ensure that the sound is identical to that of the source material. 'MQA Studio' indicates it is playing an MQA Studio file, which has either been approved in the studio by the artist/producer or has been verified by the copyright owner.'OFS' confirms that the product is receiving an MQA stream or file. This delivers the final unfold of the MQA file and displays the original sample rate.

Button & Ports



Touch control
The screen is an IPS multi-touchscreen, with 2.45' size and 360*480 resolution.

Power button
Hold down for two seconds while powered off to turn it on: hold down while powered on to turn it off.

Multicolor LED
Changes colors depending on what is playing in terms of sample rate:

Red: Charging/low battery	White: DSD
Yellow: 32k~84k	Green: MQA
Aqua: 64k~192k	Blue: MQA studio
Orange: 352.8k or above	Magenta: MQA Rendering

Micro SD card
The RS2 carries an external Micro SD slot for music storage, supporting Micro SD cards up to ≤2T. When putting in a Micro SD card for the first time or changing cards you need to scan for new songs. Connected to the computer via the supplied USB cable, the RS2 can act as a card reader for transferring music onto the micro SD card inserted into the RS2. After transferring songs please "safely eject" the card in the computer before unplugging the USB cable.

USB Type C port
For data transmission+charging+coaxial digital output. A special Type C to 3.5mm coaxial cable is required for using the coaxial digital output. It can be purchased from store.hiby.com or your local dealer. Please note that this special cable only works with the RS2.

Headphone port
Supports 3.5mm headphone out, 3.5mm line out and 4.4mm balanced. Change the output mode in the setting menu.

USB DAC
1.Please go to the official website store.hiby.com to download the driver zip file and guidance.
2.To use the RS2 as USB DAC, you need to be set USB mode to "Audio" in the system settings and connect to the computer with the supplied USB data cable.

Uncharge mode
Switch the power button to the left to disable charging from USB DAC in mode.

For further in-depth operation instructions, please scan the following QR code:



Cautions

1. Do not repair, disassemble, or place the product in a place with water.
2. When the product is not used for a long time, it is necessary to periodically charge the product to ensure battery life.
3. When you use the headphones, you will not be able to hear the external environment. For your safety, please avoid using the headphones in a dangerous environment.
4. Charging with a charger with too high voltage may damage the device. Please choose a recommended charger to charge.
5. Hold the power button for 30 seconds to force restart the device if the system crashes.

FCC WARNING

This device complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions:
(1) this device must not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
FCC Radiation Exposure Statement :
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

HiBy官方直营店 HiBy Official Online Store

官方天猫店Tmall
<https://hibysm.tmall.com>

官方直营京东店JD.com
<https://mall.jd.com/index-852084.html>

国内官网Website
www.hiby.com

海外官网International official website
<http://store.hiby.com>

想知道我们更多信息? To learn more



WeChat
微信公众号



Weibo-SINA
微博关注



Facebook
脸书关注

全国售后

请拨打 **400-8820-032** 或直接咨询您购买的店铺

Global after-sales service

Please contact us at service@hiby.com or directly contact the store you purchased from.

东莞市敏动电子科技有限公司

服务热线：400-8820-032 / 0086-769-23182216
官方网址：www.hiby.com
电子邮箱：service@hiby.com
生产地址：广东省东莞市南城街道宏伟三路39号1201室

DONGGUAN SMARTACTION TECHNOLOGY CO.,LTD.

TEL: 0086-769-23182216 Website: www.hiby.com
Email: service@hiby.com
Address: Room 1201, Lianjing Commercial Building, No.39, Hongwei 3rd Road, Nancheng District, Dongguan, Guangdong, China